



CYCLOTRONS 2010

The 19th International Conference on Cyclotrons and their Applications



Beam Diagnostics for RIBF in RIKEN

T. Watanabe, M. Fujimaki, N. Fukunishi, M. Kase,
M. Komiyama, N. Sakamoto, H. Watanabe,
K. Yamada and O. Kamigaito

RIKEN Nishina Center

R. Koyama

Sumitomo Heavy Industries Accelerator Service

Cyclotrons 2010

8 September 2010

Ning-Wo-Zhuang Hotel,
Lanzhou, China

RIBF:
Radio
Isotope
Beam
Factory

Can we watch a beam?

Purpose and importance of beam diagnostics

■ What is the purpose of beam diagnostics?

◆ These systems are our sense organ showing

(1) what properties a beam has;

(2) how it behaves in a machine.

■ Why do we need diagnostics?

Why ?

◆ If we don't use beam diagnostics,

(1) one would blindly grope around in the dark;

(2) improvements are hardly achievable.

■ Accelerator is just as good as its diagnostics !



Preview


- Purpose and importance of beam diagnostics
- Accelerator complex of RIBF
- Monitors used in beam transport line
- Monitors used in cyclotron
- Newly developed monitors
- Summary

Accelerator complex of RIBF

TUM2CIO01 Osamu Kamigaito

Beam line	FC	PF	PS	Length (m)
RRC- fRC	9	12	3	81
fRC- IRC	10	25	4	119
IRC-SRC	6	13	3	64

FC: Faraday cup
PF : Profile monitor
PS : Plastic scintillator



1 Linac + 4 Cyclotrons+
BigRIPS (Superconducting RI Separator)


- Succeeded in accelerating a U beam to 345 MeV/u in 2007
- Discovery of a new RI, a neutron-rich Pd 125, in same year
- Search for new isotopes in-flight fission of the 345 MeV/u U beam
- Discovery of new 45 neutron rich RIs in 2008

- 
- Accelerator complex of RIBF
 - Monitors used in beam transport line


Technical issues of Faraday cup

- Difficulty of suppressing of high energy secondary electrons

Beam current (enA)




- Transmission efficiency
-> 50 Faraday cups
TUM2CIO01 : Osamu Kamigaito




Modification of Faraday cup



Faraday cup used in 2007



Faraday cup used in 2008




To solve this technical issue,




Comparison of Beam Profile

■ Beam profile monitor





3 wires-
scanner type

■ ^{48}Ca beam on IRC-injection line




Plastic scintillation monitor


Black diagram



Longitudinal beam width



- Monitors used in beam transport line
- Monitors used in cyclotron



RIKEN
NISHINA
CENTER

Radial probe


Radial probe

Turn pattern comparison

$^{238}\text{U}^{86+}$

@ IRC-MDP2



■ Measured
Result




$\Delta p / p = 0.20\%$

■ Simulation


$\Delta p / p = 0.22\%$



- 
- Monitors used in cyclotron
 - Newly developed monitors



Block diagram of phase measurements by using Lock in amplifier

MOPCP094 Ryo Koyama




Measured Result by LIA

■ Good isochronous magnetic fields



■ Correlation between observed beam phases and acceleration RF




Successful measurements using ion beams -SQUID monitor-

RF cavity:
Max. 0.6 MW
Main magnetic field:
Max. 1.7 T



Radiation dose (1 year):
3.0 Sv for gamma radiation
25.5 Sv for neutrons

Beam $^{40}\text{Ar}^{+15}$ (63 MeV/u)




HTc SQUID Monitor System

Reduction of ;


- Running costs
- Frequency maintenance

of



SQUID
temperature
 $\Delta T < 5 \text{ mK } 18\text{h}$
(PID control)


Environmental
magnetic noise can
be reduced
 $1/1,000,000$




Real-time analysis

Beam $^{40}\text{Ar}^{+15}$ (63 MeV/u)


Discharge of ECR ion source




Close up




Amplitudes of ripples in modulated beam



0 hour (beam off)



0.7 h



3.8 h

- Measurements and analyses
- In real time
- Without interrupting beam user's experiments

Summary

- Purpose and importance of beam diagnostics
- Accelerator complex of RIBF
- Monitors used in beam transport line
- Monitors used in cyclotron
- Newly developed monitors

Can we
watch a beam ?

-> Yes, we can !



Thank you for your kind attention



Cyclotrons 10
banquet !
This evening !!

Tamaki Watanabe

Principle of HTc SQUID monitor

Irradiation of beam




Shielding current is produced by Meissner effect



Designed to have a bridge circuit
Current is concentrated in bridge circuit
SQUID can detect Φ with high S/N ratio

Superconductor: $\text{Bi(Pb)}_2\text{-Sr}_2\text{-Ca}_2\text{-Cu}_3\text{-O}_x$ (Bi2223)
Substrate: 99.9% MgO ceramic




Cryogenic Current
Comparator

SQUID
Readout

$$\oint_a B l = \mu(I_1 - I_2 + I_s) = 0$$


$$-I_s = I_1 - I_2 \text{ (Ampere's law)}$$



Emittance analysis of ^{48}Ca beam


IRC-injected beam

Beam Width (mm)



SRC-injected beam

Beam Width (mm)




Utilizing the data of beam widths obtained by beam profile monitors, we estimated beam emittances based on the first order ion optics.


- Emittance (IRC-injected beam) = $2.2 \sim 2.3 \pi$ mm mrad (unnormalized, within 4σ region)
- Emittance (SRC-injected beam) = $\sim 1.7 \pi$ mm mrad (unnormalized, within 4σ region)
- No notable emittance growth was observed.
- Corresponding normalized-RMS emittance is 0.19π mm mrad.

Effect of secondary electrons

Turn pattern of IRC-MDP1 (07/05/22)




Modification of SRC-MDP



Effect of secondary electrons

Turn pattern of IRC-MDP1 (07/05/22)



Modification of SRC-MDP

