

## APS Superconducting Undulator Beam Commissioning Results

Katherine Harkay for the APS SU0 Team

NA-PAC 2013, Pasadena, CA October 1, 2013



Advanced Photon Source Upgrade (APS-U) project

#### Outline

- Introduction
- Commissioning plan
- Unpowered effect on beam
- Powered effect on beam
- Thermal analysis
- Beam-based alignment
- Performance
- Conclusions



#### Introduction

- Superconducting undulators allow a higher peak magnet field compared to conventional devices, which can greatly benefit light sources.\*
- Superconducting technology was used to build a fully-functioning shortperiod test undulator (SCUO) at the Advanced Photon Source. Unique features: out-of-vacuum, thermally isolated beam chamber, cryocoolers.

Photon energy at 1st harmonic, keV20-25 keVPeriod length16 mmMagnetic gap9.5 mmDesign magnetic field0.64 TDesign operating current500 AMagnetic length0.34 mCryostat length2.063 mBeam operating current100 mA	Parameter	Value
Period length16 mmMagnetic gap9.5 mmDesign magnetic field0.64 TDesign operating current500 AMagnetic length0.34 mCryostat length2.063 mBeam operating current100 mA	Photon energy at 1 <sup>st</sup> harmonic, keV	20-25 keV
Magnetic gap9.5 mmDesign magnetic field0.64 TDesign operating current500 AMagnetic length0.34 mCryostat length2.063 mBeam operating current100 mA	Period length	16 mm
Design magnetic field0.64 TDesign operating current500 AMagnetic length0.34 mCryostat length2.063 mBeam operating current100 mA	Magnetic gap	9.5 mm
Design operating current500 AMagnetic length0.34 mCryostat length2.063 mBeam operating current100 mA	Design magnetic field	0.64 T
Magnetic length0.34 mCryostat length2.063 mBeam operating current100 mA	Design operating current	500 A
Cryostat length2.063 mBeam operating current100 mA	Magnetic length	0.34 m
Beam operating current 100 mA	Cryostat length	2.063 m
	Beam operating current	100 mA



SCU0 installed in the APS storage ring in Dec, 2012.

\* Y. Ivanyushenkov, FRYBB1 (invited)

## **Commissioning goals**

#### **Overview:**

- Detailed commissioning plan completed during extended machine startup, Jan 2013.
- SCU0 released for User operation on Jan 29.

#### Assess:

- Thermal sensor and vacuum monitoring
- Vacuum chamber layout and chamber transition heating
- Cryogenic system performance
- Orbit stability with given limits on field integral rate-of-change and absolute error requirements
- Quench response
- Field correction coil response
- Vibration effects of the cryocoolers on beam motion
- Validity of estimates of beam-induced heat load
- Alignment procedures
- X-ray performance
- Storage ring operation procedures

#### Vacuum performance

#### Vacuum pressure history, cold cathode gauge

After installation, rough-down prior to bakeout	~2×10 <sup>-7</sup> Torr
After bakeout of up/downstream transitions	3 nTorr
After SCU0 cooldown, prior to beam injection	0.4 nTorr
After first 100-mA beam (transients)	~10 nTorr
After 10 Amp-hr of beam operation (~4 days)	~3 nTorr
After 200 Amp-hr of beam operation (~3 mos.)	~0.8 nTorr

No beam chamber vacuum pressure issues and no negative effects observed on the beam.



## Impact of SCU0 on beam operation

- Field integral measurement with beam
  - Variation in field integral was inferred from effort of nearby steering correctors.
  - Field integrals agree reasonably well with magnet measurements\* in preliminary comparison.
- Effect of induced quench on beam
  - Beam motion is small, even without fast orbit feedback running, as in this example.
  - Quench does not cause loss of beam
  - Beam position limit detectors were not triggered.



#### Quenches

- Device has quenched during unintentional beam dumps. Procedures to mitigate these quenches are under investigation. Device is powered down prior to planned beam dumps.
- With the exception of beam dumps, the device quenched only twice in 8 months of user operations, operating above its 500-A design current. Stored beam was not lost, and total SCU0 downtime was < 1 hr.



induced by sudden

temperatures recover quickly

#### Thermal analysis, beam-induced heat load in SCU0

- Protection of SCU0 from excessive beam-induced heat load a key requirement.
- All standard bunch modes were tested at 100 mA; also in a special 150-mA run.
- Predicted image-current heat loads\* were compared with the measured heat load using the cryocooler thermal load map (20-K circuit).
- Remarkable agreement, within 1-2 W.
  - \* Synchrotron radiation and wakefield heat load is < 1 W.

Harkay for APS SCU0 Team	NAPAC2013	Pasadena, CA
--------------------------	-----------	--------------

Total beam current/ number of bunches	Calculated heat load * (W)	Measured heat load, cryocooler load map (W)
100 mA		

24	16.0	14.3
324	2.0	3.4
1+56	11.1	10.8

#### 150 mA

324 4.6	6.2
---------	-----

#### \* K. Harkay et al., WEPSM06 (poster)

#### Measured SCU0 chamber temperatures vs. thermal modeling\* 2 3 4 5 6





- Analytical imagecurrent heat load modeled using ANSYS.\*
- Modeled chamber temperatures are within 10% of the measured temperatures.

\* Y. Shiroyanagi et al., THPAC07 (poster)

# Beam-based alignment (BBA) of SCUO chamber using thermal sensors

- Net resistive wall heating increases when the beam is not centered in the chamber.
- This can be used to find the vertical center of the chamber.
- Radiation from the upstream bending magnet can potentially strike the cold chamber.
- BPMs at the dipole are used to steer the beam and minimize the temp.\*\*
- Beam steering in the dipole also shows a vertical chamber displacement, consistent with the ID beam steering.

K. Harkay for APS SCU0 Team NAPAC2013 Pasadena, CA



<sup>\*\*</sup> L. Boon et al., THPAC06 (poster)

## Measured SCU0 chamber alignment\* (ID steering)

- A vertical chamber offset of ~0.3 mm was detected with 100-µm accuracy.
- Accuracy is 10× better than with aperture scan.
- Further benefits of thermal sensor-based BBA:
  - Isolates SCU0 chamber alignment from other vacuum components in the orbit bump.
  - Provides longitudinal spatial resolution (1.6 m length shown).



## SCU0 performance

- Designed for operation at 500 A; operates reliably at 650-700 A over 50% of the time.
- Designed for 100 mA beam; operated with 150 mA and no significant issues were identified.
- Magnet cores held at ~4 K even with 16 W of beam power on the beam chamber.
- No loss of He was observed in an 8-month period.



Measured temperatures in the SCU0 cryostat at beam current of 100 mA (24 bunches), SCU0 magnet is off.

## SCU0 X-ray performance

- Photon flux of SCU0 was compared with an in-line 3.3-cm-period length permanent magnet hybrid undulator (U33), using a bent-Laue monochromator.
- At 85 keV, the 0.34-m-long SCU0 produced ~45% higher photon flux than the 2.3-m-long U33.



Photon flux comparisons at 85 keV. Main: Simulated and measured SCU0 photon flux . Inset: Measured photon flux for in-line U33.

K. Harkay for APS SCU0 Team NAPAC2013 Pasadena, CA

#### Conclusions

- An almost decade-long R&D program on development of superconducting undulators at APS was successfully completed in Dec. 2012 with the installation of the first test undulator in the APS storage ring.
- Beam commissioning was highly successful and the measured parameters agree very well with the predictions. All the requirements were satisfied:
  - Cryomodule integrity/operability preserved during installation.
  - Unpowered SCU0 transparent to normal user operation; i.e., does not measurably increase storage ring impedance, or decrease injection efficiency or lifetime.
  - Powered SCU0 does not perturb the beam more than allowed.
  - SCU0 sufficiently protected from beam-induced heat loads.
- Device is in user operation since Jan. 2013, operating reliably above its design current, delivering enhanced photon flux at energies above 50 keV.

## **Mechanical vibration**

- Cryocooler vibration measured at three locations:
  - 1. Beam chamber, 40 cm upstream of SCU0
  - 2. Vacuum vessel, beam height
  - 3. Support girder base (not shown)
- Results for beam chamber shown at right.
- Cryocooler vibration was not observed to adversely affect the beam motion.



Integrated power density (µm rms),		
Cryocoolers off	0.38	
Cryocoolers on	0.50	
	0.00	
Amplitude at	: 8.375 Hz (µm rms)	

0.06

0.57

Cryocoolers off