

Cold Test Results of the ISAC-II Medium Beta High Gradient Cryomodule

R.E. Laxdal, I. Bylinskii, G.S. Clark, K. Fong, A.K. Mitra, R. L. Poirier,
B. Rawnsley, T.R. Ries, I. Sekachev, G. Stanford, V. Zvyagintsev
TRIUMF, Vancouver, Canada


Outline:

- Overview
- Cryomodule
 - Developments/Hardware
- Results

ISAC-II Building




The ISAC - II Accelerator Floor



Linac Vault



Test Area




Assembly Area




ISAC-II SC Linac

ISAC-II Cryomodules




Medium Beta Cavities



(a) Nominal ($\beta=7.1\%$)

(b) Flat ($\beta=5.7\%$)

Single Cavity Tests




Section	β_0 (%)	f_{RF} MHz	No.	E_p MV/m	E_a MV/m
Low β	4.2	70.7	8	25	5
Med β	5.7	106	8	30	6
	7.1	106	12	30	6
High β	10.4	141	20	30	6

Medium Beta Cryomodule

□ Design Features

- Stainless steel vacuum enclosure
- LN2 cooled copper shield
- mu metal for magnetic field suppression




Lid Assembly in Assembly Frame




Superconducting Solenoids

- ❑ Focussing in the SC Linac is provided by superconducting solenoids ($B \leq 9\text{T}$)
- ❑ End fringe fields controlled with active 'bucking' coils ($B_{\text{cavity}} \leq 0.1\text{T}$)
- ❑ Production Medium and High beta solenoids in fabrication at Accel
 - See table for specifications



Specifications

	Low β	Med β	High β
Field	9T	9T	9T
Bore	26mm	26mm	26mm
Number	4	5	3
Eff. Length	16cm	34cm	45cm



RF Systems

□ RF power

- Provide useable bandwidth by overcoupling
- Require $P_f=200\text{W}$ at cavity for $f_{1/2}=20\text{Hz}$ at $E_a=6\text{MV/m}$, $\beta=200$

□ Coupling loop

- Developed LN2 cooled loop
- $<0.5\text{W}$ to LHe for $P_f=250\text{W}$


□ Mechanical tuner

- Precise (0.3~Hz), fast ($>50\text{Hz/sec}$) tuner with dynamic range of 8kHz and coarse range of 32kHz


□ Tuning plate

- Spun, slotted, 'oil-can' tuning plate to improve tuning range

Forward power required for $E_a=6\text{MV/m}$ and given bandwidth



Coupling Loop



Mechanical Tuner




ISAC-II Mechanical Tuner


- ❑ Deflects niobium tuning plate at base of cavity (6 Hz/ μm)
- ❑ Lever mechanism with zero backlash hinges and stiff rod connected to precision linear motor (Kollmorgan) in air
- ❑ In cold tests control loop was phase locked and tuner maintained frequency during rapid forced helium pressure fluctuations up to 60Hz/sec




Low Field ($E_a=1.8\text{MV/m}$), $f_{1/2}=25\text{Hz}$



Moderate Field ($E_a=3.7\text{MV/m}$), $f_{1/2}=15\text{Hz}$




High Field ($E_a=6.3\text{MV/m}$), $f_{1/2}=12\text{Hz}$



Coupling Loop with Direct Cooling



- ❑ Developed from INFN Legnaro adjustable coupling loop
- ❑ Modifications
 - ✓ Stainless steel body for thermal isolation
 - ✓ Copper outer conductor thermally anchored to copper LN2 cooled heat exchange block
 - ✓ Aluminum Nitride dielectric inserts thermally anchor the inner conductor to the outer conductor
 - ✓ Removed fingerstock to control microdust
- ✓ Achieved $<0.5W$ helium heating with $P_f=250W$




Cryomodule Alignment

- ❑ the tolerance on solenoid and cavity misalignments are $\pm 200 \mu\text{m}$ and $\pm 400 \mu\text{m}$ respectively
- ❑ we have collaborated with INFN Milano on the development of a Wire Position Monitor for cold alignment with precision of $20 \mu\text{m}$
 - Stripline monitor attached to each device driven by rf signal along a reference wire


WPM Monitors on Cavities



Wire Position Stripline Monitor





Cryomodule Cold Test – June 2004




Cavity Performance

- All cavities locked at reference frequency
- Three cavities locked simultaneously
 - Hardware problem with one control board
- Low level Q values all $>1e9$
 - Mu metal field reduction is adequate
- Field emission at high field
 - Cavities not rinsed prior to test
 - Require more conditioning time



Solenoid Test



- Base Q's measured before solenoid test
- Ramp up solenoid to 9T
 - Cavities 2 and 3 on
 - No quench of cavities or solenoid
 - No change in cavity Q
- Cold mass warmed above transition
- Q's measured after second cooldown
 - No change; $Q > 1e9$
 - Residual field tolerable



No negative impact on cavities from operation of solenoid

Cryomodule Static Load

- April 25 – First cooldown
 - 200ltr LHe accumulated in cryomodule
 - After thermalization boil-off equivalent to **11W** static load
- July 2 – Second cooldown
 - 180ltr LHe accumulated in cryomodule
 - After thermalization boil-off equivalent to **16W** static load



Conclusion

- First cryomodule rf cold test was very successful
- Highlights
 - All cavity Q's $> 1e9$
 - All cavities locked
 - Three cavities locked simultaneously with solenoid on
 - Solenoid ramped to 9T
 - No impact of solenoid on cavity performance from operating field or from remnant fields
 - Static load within design limits - 16W

ISAC-II Contributions

- MOP86 – Cryomodule Cold Test – R. Laxdal
- MOP86 – RF Coupling Loop Design – R. Poirier
- MOP89 – Wire Position Monitor – B. Rawnsley
- TUP77 – RF Control System – K. Fong
- TU104 – ISAC Overview/Plans – P. Schmor
- THP14 – Cryomodule Engineering – G. Stanford
- THP14 – High Beta Cavity Design – R. Laxdal